

REC BATTERY MANAGEMENT SYSTEM MASTER-SLAVE CONFIGURATION




Control your power!

Novi trg 9, 6230 Postojna, Slovenia
mail: info@rec-bms.com; www.rec-bms.com

Features:

- REC Master 10M unit + up to 12 BMS Slave units configuration (in series or in parallel connection)
- up to 8 digital temperature sensors DS18B20 per BMS Slave device
- single cell voltage measurement (0.1 – 5.0 V, resolution 1 mV)
- single cell - under/over voltage protection
- single cell internal resistance measurement
- SOC and SOH calculation
- over temperature protection
- under temperature charging protection
- 4.0 Ω passive cell balancing
- current measurement with shunt sensor (resolution 19.5 mA @ \pm 500 A)
- internal battery powered real time-clock (RTC)
- galvanically isolated user-defined multi-purpose relay and digital output
- 3 additional internal relays output (normally open)
- galvanically isolated RS-485 communication protocol
- galvanically isolated CAN bus
- error LED + buzzer indicator
- error acknowledged and forced connect function
- wide range power supply voltage (10.5 - 90 V)
- monitoring parameters, managing settings, and data-logging through a Wi-Fi module on any PC or smart mobile device (as an optional accessory)
- hibernate switch
- ISO16315, ISO10133, EN61558-1, EN61558-2 and EN50498 compliant

INDEX:

General Description of the Battery Management System:.....	4
Hardware Parameters:.....	5
Default Software Parameters:	7
System Overview:	8
REC 2Q BMS Slave Unit Connections:	9
Setting Number of Cells and the RS-485 Address:.....	12
BMS Unit Cell Connector:.....	13
BMS Unit Power Supply:	14
Paralleling Cells – Increasing Battery Capacity:	16
BMS Unit Connection Instructions:.....	17
BMS Unit Start Procedure:.....	18
REC BMS Slave Unit LED Indication:.....	18
Cell Voltage Measurement:	18
Battery Pack Temperature Measurement:	18
BMS Current Measurement:.....	19
Master 10M Unit:.....	21
Power Supply:	23
Remote ON/OFF input:	23
Master 10M Relay Outputs:.....	23
Digital Output:.....	24
Control Pilot CP:	24
Error Acknowledge/Forced Connect Input:	24
RS-485 Communication Protocol:.....	25
Master 10M RS-485 Communication with BMS Slave Units:.....	30
CAN Communication:.....	31
Victron.....	33
Master 10M Unit Start Procedure:	36
Master 10M Unit LED Indication:.....	36
Voltage/Temperature Hysteresis:.....	36
BMS Cell Balancing:.....	36
Balancing START Voltage (BMIN):.....	37
Balancing Voltage END (BALV):.....	37
Cell Internal DC Resistance Measurement:	37
Battery Pack SOC/SOH Determination:.....	37
Battery Pack’s Charging Algorithm:	38

Maximum Cell Float Voltage Coefficient (CFVC):.....	39
Battery Pack's Discharging Algorithm:	40
System Error Indication:.....	42
BMS Slave Unit Dimensions:	46
Master 10M Unit Dimensions:	46

General Description of the Battery Management System:

The Battery Management System (BMS) monitors and controls each cell in the battery pack by measuring its parameters. The capacity of the battery pack differs from one cell to another, and this increases with number of charging/discharging cycles. The Li-poly batteries are fully charged at typical cell voltage 4.16 - 4.20 V or 3.5 – 3.7 V for LiFePO₄. Due to the different capacity this voltage is not reached at the same time for all cells in the pack. The lower the cell's capacity the sooner this voltage is reached. When charging series connected cells with a single charger, voltage on some cells might be higher than the maximum allowed voltage. Overcharging the cell additionally lowers its capacity and number of charging cycles. The BMS equalizes cell's voltage by diverting some of the charging current from higher voltage cells to power resistors – passive balancing. The device's temperature is measured to protect the circuit from over-heating due to unexpected failure. The Dallas DS18B20 digital sensor monitors the battery pack's temperature. Maximum 8 temperature sensors per REC BMS Slave unit may be used. Current is measured by a low-side shunt resistor. Battery pack's current, temperature and cell's voltage determine state of charge (SOC). State of health (SOH) is determined by comparing cell's current parameters with the parameters of a new battery pack. The REC BMS Slave unit's default hardware (HW) parameters are listed in Table 1.

Hardware Parameters:

Table 1: REC BMS Slave unit hardware parameters.

PARAMETER	VALUE	UNIT
BMS maximum pack voltage	68.0	V
BMS minimum pack voltage	10	V
BMS minimum pack voltage (HW UVP)*	-	V
BMS cell voltage range	0.0 to 5.0	V
Shunt common mode input voltage interval (Shunt+, Shunt -) to the Cell 1 negative	-0.3 to 3.0	V
Shunt sensor max differential input voltage interval (Shunt+ to Shunt -)	-0.25 to 0.25	V
Cell voltage accuracy	+/-1	mV
Pack voltage accuracy	+/-5	mV
DC current accuracy	+/- 1	LSB
Temperature measuring accuracy	+/-0.5	°C
DC Current sample rate	4	Hz
Cell voltage sample rate	1	Hz
Cell balancing resistors	4.0	Ω
Maximum operating temperature**	70	°C
Minimum operating temperature**	-20	°C
Maximum storage temperature**	30	°C
Minimum storage temperature**	0	°C
Maximum humidity**	75	%
Max continuous DC current opto-relay @ 100 V DC	3	A
BMS unit disable power supply @ 48 V	1.5	mW
BMS pre-charge resistance	25	Ω
BMS unit operation power supply @ 48 V	180 - 190	mW
BMS unit cell balance fuse rating	3 slow	A
Internal relay fuse	3.15 slow	A
Internal RTC battery	CR1632	n.a.
Dimensions (w × l × h)	190 x 98.4 x 38	mm
IP protection	IP32	
HW version	1.36/1.37	n.a.

*installed on request

**defined by internal RTC back-up 2032 battery

Table 2: REC Master 10M unit hardware parameters.

PARAMETER	VALUE	UNIT
REC Master 10M maximum supply voltage	10.5	V
REC Master 10M minimum supply voltage	90	V
REC Master 10M minimum supply voltage (HW UVP)*	10.4	V
BMS maximum cell voltage	5.0	V
Cell voltage sample rate	1	Hz
Maximum operating temperature	70	°C
Minimum operating temperature	-20	°C
Maximum storage temperature	30	°C
Minimum storage temperature	0	°C
Maximum humidity	75	%
Max continuous DC current relay @ 60 V DC	0.7	A
Max continuous AC current relay @ 230 V AC	2	A
ACK/forced connect digital input impedance	47	kΩ

Internal relay fuse	3.15 slow			A
Max DC current @ optocoupler 1	15			mA
Max DC voltage@ optocoupler 1	85			V
REC Master 10M unit disable current supply @ 12 V	0			mA
REC Master 10M unit stand-by current supply @ 12 V**	17	18	19	mA
REC Master 10M unit stand-by current supply @ 24 V**	8	9	10	mA
REC Master 10M unit stand-by current supply @ 48 V**	6	6.5	7	mA
REC Master 10M unit stand-by current supply @ 80 V**	3	3.5	4	mA
Internal RTC battery	CR1632			n.a.
Dimensions (w × l × h)	190 x 98 x 38			mm
IP protection	IP32			
HW version	1.1			n.a.

*installed on request, may be set from 12 to 60 V.

**relays and optocouplers all off.

Default Software Parameters:

Table 3: Default Master 10M unit parameter settings*.

PARAMETER	VALUE	UNIT
Chemistry	3 (LiFePO ₄)	n.a.
Capacity	280	Ah
Balance start voltage	3.45	V
Balance end voltage	3.55	V
Cell over-voltage switch-off per cell	3.75	V
Over-voltage switch-off hysteresis per cell	0.20	V
Cell end of charge voltage	3.55	V
End of charge hysteresis per cell	0.25	V
SOC end of charge hysteresis	5	%
Maximum cell float voltage coefficient	0.5	n.a.
Cell-under voltage protection switch-off	2.80	V
Under voltage protection switch-off hysteresis per cell	0.10	V
Cell under voltage discharge protection	2.95	V
Battery pack under voltage protection switch-off timer	2	s
Cells max difference	0.25	V
SOC discharge hysteresis	5	%
BMS over-temperature switch-off	55	°C
BMS over-temperature switch-off hysteresis	5	°C
Cell over temperature switch-off	55	°C
Cell over temperature switch-off hysteresis	2	°C
Under temperature charging disable	0	°C
Under temperature charging disable hysteresis	2	°C
Voltage to current coefficient – BMS Slave units	0.01953125	A/bit
Integrated pre-charge time – BMS Slave units	4	s
Current measurement zero offset – BMS Slave units	0.0	A
Maximum charging/discharging current per inverter device	100/150	A
Number of inverter/charger devices	1	n.a.
Charge coefficient	0.6	1/h
Discharge coefficient	1.5	1/h
CAN communication frequency	250	kbit/s
System configuration (serial/parallel)	serial	n.a.
Forced connection timer	10 + precharge timer	s
Relay 1 digital output task	disabled	n.a.
Optocoupler 1 digital output task	disabled	n.a.
SW version	2.1	n.a.

*all parameters' values may be changed with user interface by Wi-Fi module.

System Overview:




Figure 1: System overview - serial HV connection.




Figure 2: System overview - parallel connection.

REC 2Q BMS Slave Unit Connections:




Figure 3: REC 2Q BMS Slave unit function overview.




Figure 4: REC 2Q BMS Slave unit connections description.

Table 4: RS-485 communication output connector’s pin description.

Pin	Connection	Description	Plug
1	RS-485 B out	Signal B out	794190-1
2	RS-485 A out	Signal A out	
3	RS-485 +5 V ENABLE out	Master 10M unit controlled REMOTE ON/OFF	
4	RS-485 +5 V out	RS-485 +5 V Power supply	
5	RS-485 GND out	RS-485 Power supply GND	
6	RS-485 CABLE SHIELD out	SHIELD OUT	

Table 5: RS-485 communication input, CAN communication and Control Pilot connector's pin description.

Pin	Connection	Description	Plug
1	-	-	794202-1
2	-	-	
3	-	-	
4	-	-	
5	RS-485 +5 V ENABLE in	Master 10M unit controlled REMOTE ON/OFF	
6	RS-485 B in	Signal B in	
7	RS-485 A in	Signal A in	
8	-	-	
9	-	-	
10	-	-	
11	-	-	
12	RS-485 CABLE SHIELD in	SHIELD IN	
13	RS-485 GND	RS-485 Power supply GND	
14	RS-485 +5V	RS-485 +5 V Power supply	

* Galvanically isolated CAN communication is upgraded upon request.

Table 6: Power supply, cell measurement and pre-charge connector's pin description.

Pin	Connection	Description	Plug
1	CELL 1-	Cell 1 negative (PACK -)	794210-1
2	CELL 2+	Cell 2 positive	
3	CELL 4+	Cell 4 positive	
4	CELL 6+	Cell 6 positive	
5	CELL 8+	Cell 8 positive	
6	CELL 10+	Cell 10 positive	
7	CELL 12+	Cell 12 positive	
8	CELL 14+	Cell 14 positive	
9	CELL 16+	Cell 16 positive	
10	PRE-CHARGE OUT	Pre-charge out – connect to System + side of the contactor (parallel string system only)	
11	PACK-	BMS Power supply negative (Cell 1 negative)	
12	CELL 1+	Cell 1 positive	
13	CELL 3+	Cell 3 positive	
14	CELL 5+	Cell 5 positive	
15	CELL 7+	Cell 7 positive	
16	CELL 9+	Cell 9 positive	
17	CELL 11+	Cell 11 positive	
18	CELL 13+	Cell 13 positive	
19	CELL 15+	Cell 15 positive	
20	PACK +	BMS Power supply positive	

Table 7: Current and temperature sensor connector's pin description.

Pin	Connection	Description	Plug
1	1-WIRE GND port 1	1-WIRE temperature sensor DS18B20 Supply GND	794196-1
2	1-WIRE SIGNAL port 1	1-WIRE temperature sensor DS18B20 signal	
3	1-WIRE +5 V port 1	1-WIRE temperature sensor DS18B20 Supply +5 V	
4	CURRENT SENS -	Shunt sensor Kelvin connection negative	
5	CURRENT SENS CABLE SHIELD	Current sensor cable shield	
6	1-WIRE GND port 2	1-WIRE temperature sensor DS18B20 Supply GND	
7	1-WIRE SIGNAL port 2	1-WIRE temperature sensor DS18B20 signal	
8	1-WIRE +5 V port 2	1-WIRE temperature sensor DS18B20 Supply +5 V	
9	CURRENT SENS +	Shunt sensor Kelvin connection positive	
10	-	-	

*BMS Slave unit with address 1 only.

Table 8: Remote ON/OFF and I/O connector's pin description.

Pin	Connection	Description	Plug
1	-	-	794192-1
2	-	-	
3	OPTO-RELAY OUT	Opto-relay output signal	
4	REMOTE ON/OFF -	BMS Remote ON/OFF input	
5	-	-	
6	-	-	
7	OPTO-RELAY IN	Input supply + for the OPTO – RELAY (parallel string system only)	
8	REMOTE ON/OFF +	BMS Remote ON/OFF source (connect to REMOTE ON/OFF – pin 4 to enable the BMS or use RS-485 +5 V ENABLE to turn the BMS Slavees on)*	

*BMS Slave unit may be turned ON by the Remote ON/OFF button or automatically by the Master unit using RS-485 +5 V ENABLE connection.

For all TE Connectivity plugs we recommend using mini-universal MATE-N-LOK socket contact [794221-1](#).

Setting Number of Cells and the RS-485 Address:

Before powering the device, the end user must set the correct number of cells that will connect to the unit and **if multiple BMS units are used it is also required to set a unique address for each unit to avoid data collision on the RS-485 communication bus.**

The number of cells connected to the BMS unit is selected via the **CELLS** rotary switch, while the BMS address is set via **ADDR** rotary switch at the back of the BMS unit. Users are required to configure between 4 and 16 cells, with addresses ranging from 1 to 15. Address 16 is used for Master unit 10M.



Figure 5: BMS address and cell selection rotary switches.

Table 9: BMS address - **ADDR** settings.

Selection	Setting
0	Address 0 (ERROR 6)
1	Address 1
2	Address 2
3	Address 3
4	Address 4
5	Address 5
6	Address 6
7	Address 7
8	Address 8
9	Address 9
A	Address 10
B	Address 11
C	Address 12
D	Not recognizable
E	Not recognizable
F	Not recognizable

Table 10: Number of cells - **CELLS** settings.

Selection	Setting
0	1 cell (ERROR 6)
1	2 cell (ERROR 6)
2	3 cells (ERROR 6)
3	4 cells
4	5 cells
5	6 cells
6	7 cells
7	8 cells
8	9 cells
9	10 cells
A	11 cells
B	12 cells
C	13 cells
D	14 cells
E	15 cells
F	16 cells

BMS Unit Cell Connector:

Connect BMS power supply, each cell and pre-charge BMS cell connector 20-pin plug. We recommend using silicon wires with a cross section of 0.5 – 1 mm².

! Before inserting the cell connector check the voltage level and polarity of each connection!

! When working on cells/connections – the BMS' cells connector must be unplugged, otherwise the BMS may be damaged!




Figure 6: Battery pack BMS cell connector.

BMS Unit Power Supply:

BMS unit is always powered from the PACK + and PACK – connections. **An additional connection from the battery pack positive voltage (Pack +) and the battery pack negative voltage (Pack -) should be connected to pins 20 and 11.** Do not bypass the Cell 1- and the highest cell to this connection. It decreases the measurement accuracy since the power is connected through the measurement cells connection.




Figure 7: BMS unit power supply.

If multiple BMS units are used in series, care should be taken how to connect each. Two separate wires should be wired to the same cell: first wire for the lower BMS Slave unit as the end-cell voltage potential, and second wire as GND potential for the higher BMS Slave unit. See Fig. 7!

Do not bypass the higher cell!




Figure 8: Multiple BMS Slave units for series cell connection.

Paralleling Cells – Increasing Battery Capacity:

Battery capacity may be increased in two ways. First, by adding an additional parallel string using identical cells. This approach utilizes the REC Master 10M unit together with multiple REC 2Q BMS Slave units configured in a Master-Slave arrangement. The second method is to create parallel connections at the cell connection level. In this method, cells are grouped in parallel to form a sub-pack, and these sub-packs are later connected in series. It is essential that the design of these parallel connections ensures an even distribution of current among all the parallel cells within the sub-pack.

Lithium cells are known for their very low DC impedance, typically less than 1 mOhm. If a sub-pack is connected such that there is a 1 mOhm difference in cell connection impedance, the cell with the lowest connection resistance will experience double the current flowing in and out. This imbalance can lead to that particular cell operating at a higher temperature, resulting in faster self-discharge and accelerated aging compared to the other cells in the sub-pack.

It is important to note that this is a centralized BMS system and it is not suitable for connection of multiple sub-packs with a power cable between them. Such type of connection increases the internal impedance, which can cause a voltage rise or drop on adjacent cells. In these scenarios, a distributed BMS is recommended to ensure proper management and safety of the battery system.




Figure 9: Parallel cell connection.

BMS Unit Connection Instructions:

Connect the BMS unit to the system by the following order described in Fig. 10. It is important to disable all the BMS functions by turning enable switch OFF before plugging in any connectors. **All cells should be connected last and simultaneously.** When all the system components are plugged in, the enable switch can be turned ON and the BMS starts the test procedure. RS485 +5V ENABLE may be used for Master 10M unit remote ON/OFF.




Figure 10: BMS connection/disconnection procedure.

When disconnecting the unit from the battery pack, the procedure should be followed in reverse order.

BMS Unit Start Procedure:

When the BMS is turned ON it commences the test procedure. BMS checks if the user tries to upload new firmware. After the timeout the RED error LED turns on to signal the system's test procedure. The procedure starts by testing the balancing switches, the BMS address and cells number, temperature sensor/s detection, self-calibration and EEPROM memory parameters. The test completes in under 2 seconds. In case of no Errors the RED LED turns off and the BMS unit starts working in normal mode after a beeping sound.

If an error is detected a sound alarm/blinking red LED signal will notify the user. Each error is coded to a number. The most common errors at system startup are listed below.

- Error 6 = improper DIP switch setting.
In case of Address=0 or 16 or a cell number <4, error 6 informs the user to properly set the rotary switches. BMS has to be turned off before the pins are changed.
- Error 8 = temperature sensor not detected.
- Error 10 = reference/BMS temperature measurement failure
- Error 15 = balancing transistor failure
- Error 16 = TWI communication failure

An overview of all possible system errors is presented in the System Error Indication Section.

REC BMS Slave Unit LED Indication:

Power LED (green) signals the state when the BMS Slave unit is measuring its battery pack values.

Error LED (red) is turned on in case of system error and signals the error number with 50 % duty cycle. Between repeated error number 1 s timeout is introduced.

Cell Voltage Measurement:

Cell voltages are measured every second. The cell measurement performs 16-bit 4 ms cell measurement by Sigma Delta ADC. Each cell voltage is measured after the balancing fuse, in case the fuse blows, BMS signals error 10 or 15 to notify the user.

Battery Pack Temperature Measurement:

Battery pack temperatures are measured by Dallas DS18B20 digital temperature sensor/s. Up to two sensors can be used in parallel @ each 1-wire port, connected directly to the wiring. Up to 8 sensors may be used with a junction box and custom firmware. BMS should be turned off and the sensor 10-pin connector should be disconnected before adding sensors. Temperature sensors use shielded 3-wire cable and a common mode line chock to prevent EMI. Cable length should be as short as possible. Placing temperature cable near the power connection should be avoided. Route temperature sensor 90° to the power cable to avoid EMI that may cause communication error no. 8.

BMS Current Measurement:

Low-side only precision shunt resistor for current measurement is used on the BMS Slave unit with address 1. Connect the shunt as close as possible to the battery negative power connection (cell 1-). Fuses or manual DC switch should be placed to the system positive – before the contactor, since the CAN GND may be supplying the inverter negative rail.

A 4-wire Kelvin connection is used to measure voltage drop on the resistor. As short as possible **shielded cable** should be used to connect the power shunt and BMS Slave unit. The average battery pack current is calculated in every measurement cycle. A high precision Sigma-Delta ADC is used to filter out the current spikes. The first current measurement is timed at the beginning of the cell measurement procedure for a proper internal DC resistance calculation. Four more 300 ms measurements are performed throughout the whole BMS measurement interval. Current sensor shunt connection is shown on Fig. 11. If the BMS measures charging/discharging current that is higher than the double value of the rated shunt for more than 2 consecutive cycles, error 12 is triggered. This serves for a shunt, contactor and fuse protection in case of the short circuit.




Figure 11: Current sensor shunt resistor connection.

Different size and resistance shunts can be used, since the voltage-to-current coefficient can be changed in user interface with command `IOJA x.xxxx` or selected from the drop menu in the REC Wi-Fi module Settings tab. Offset may be corrected using `IOFF x.xx` instruction. Non-listed shunts coefficients should be entered manually. Current is calculated by the voltage drop at the shunt resistor. 1 LSB of the 18-bit ADC represents different current values according to the shunt resistance. The LSB coefficient can be calculated as:

$$k_{LSB} = 0.01171875 \cdot \frac{0.05 \text{ V}}{300 \text{ A}} \cdot \frac{I_{\text{currentx}}}{V_{\text{dropx}}}$$

where the V_{dropx} represents the voltage drop on shunt resistor at current I_{currentx} .

Table 11: Voltage-to-current coefficients for typical shunt resistors.

SHUNT RESISTOR	VOLTAGE-TO-CURRENT COEFFICIENT SETTING
100 A/50 mV	0.00390625
200 A/50 mV	0.00781250
300 A/50 mV	0.01171875
500 A/50 mV	0.01953125

Master 10M Unit:




Figure 12: Master 10M unit function overview.




Figure 13: Master 10M connections description.

Table 12: RS-485 COM communication output connector’s pin description to Wi-Fi/PC user interface.

Pin	Connection	Description	Plug
1	RS-485 B COM	Signal B COM	794190-1
2	RS-485 A COM	Signal A COM	
3	-	-	
4	RS-485 +5 V COM	RS-485 +5 V Power supply	
5	RS-485 GND COM	RS-485 Power supply GND	
6	-	-	

Table 13: RS-485 communication output, CAN communication description.

Pin	Connection	Description	Plug
1	-	-	794202-1
2	CAN TERMINATION L	120 Ω CAN termination low	
3	CAN L	CAN signal low	
4	-	-	
5	RS-485 +5 V REMOTE ENABLE SLAVE	BMS Enable input from Master 10M unit in Master-Slave configuration – remote SLAVE ON	
6	RS-485 B SLAVE	Signal B SLAVE	
7	RS-485 A SLAVE	Signal A SLAVE	
8	-	-	
9	CAN TERMINATION H	120 Ω CAN termination high	
10	CAN H	CAN signal high	

11	CAN GND	CAN ground - galvanically isolated from BMS supply GND	
12	RS-485 CABLE SHIELD SLAVE	SHIELD SLAVE	
13	RS-485 GND SLAVE	RS-485 Power supply GND	
14	RS-485 +5V SLAVE	RS-485 +5 V Power supply	

* Galvanically isolated CAN communication is upgraded upon request.

Table 14: Power supply, remote on/off, IOs and CP connector's pin description.

Pin	Connection	Description	Plug
1	Relay 4 – fused input	Relay 4 internal fused input	
2	Relay 4 - NO	Relay 4 output	
3	Relay 3 – fused input	Relay 3 internal fused input	
4	Relay 3 - NO	Relay 3 output	
5	Relay 2 – fused input	Relay 2 internal fused input	
6	Relay 2 - NO	Relay 2 output	
7	Relay 1 – fused input	Relay 1 internal fused input	
8	Relay 1 - NO	Relay 1 output	
9	Master 10M remote ON/OFF positive	Master 10M remote ON/OFF positive – short to pin 19 for remote OFF (do not connect any voltage source)	
10	Master 10M supply +	Master 10M power supply positive (10.5-90 V)	
11	CP AGND	EVSE CP signal negative	
12	CP Positive	EVSE CP signal	
13	OPTOCOUPLER 1 EMITTER	Optocoupler 1 emitter (negative)	
14	OPTOCOUPLER 1 COLLECTOR	Optocoupler 1 collector (positive)	
15			
16			
17			
18			
19	Master 10M remote ON/OFF negative	Master 10M remote ON/OFF negative - power supply negative potential (do not connect any voltage source)	
20	Master 10M supply GND	Master 10M power supply negative	

Power Supply:

Supply voltage is limited to 10.5 – 90 V DC by internal protection circuit with a reverse polarity protection. Under-voltage protection UVP is set to 10.4 V. Power consumption differs according to the switched-on relays, digital IOs and communication. If no relay is turned on, the Master 10M unit consumes about 220 mW of power @ 12 V. Power supply entry is not isolated from the rest of the circuit. CAN bus and RS485 COM bus are galvanically isolated from the Master unit supply. Voltage spikes over 90 V may reset the Master by enabling OV protection circuit.

Remote ON/OFF input:

Remote ON/OFF input is used to remotely turn ON or OFF the Master 10M unit. It shorts its under-voltage enable protection UVP to supply negative. If the connection between pins 2 and 12 is opened, Master 10M is in turns ON, while if the connection between pins is shorted, Master 10M turns OFF.

Do not apply any voltage source to pins 2 and 12.

Master 10M Relay Outputs:

Relay 1 is a user defined relay output. Its function is set with Wi-Fi module in “TASK” tab under the description “Relay 1”.

Master 10M unit - relays 2, 3 and 4 are used to pre-charge the input capacitors of inverter/s or controllers and prevent high in-rush currents. Relay 3 is programmed as the time configurable (*PRCT*) pre-charge relay. Relay 3 and Relay 2 (negative DC rail DC-) start at the same time. After the configured time delay, Relay 4 (positive DC rail DC+) turns on and relay 3 turns off. Pre-charge should be performed by using an external power resistor to enable 2-4 A of initial current @ empty capacitors (82 – 240 Ohm @ 400 V). System input capacitors should be pre-charged to 80-90 % of the battery voltage in the set pre-charge time delay. Consider the power rating of the resistor in your design. Relays 2-4 are controlled this way in case of serial or parallel string system configuration.




Figure 14: Master 10M unit contactors control electrical schematics.

Digital Output:

Master 10M unit offers a single digital output – OPTOCOUPLER 1. It uses Darlington NPN transistor optocoupler and employs over-voltage protection using SMBJ90A 90 V, reverse voltage output protection with BAT46WH 100 V diode and an over-current protection using a 160 mA resettable fuse.

OPTOCOUPLER 1 function is set with Wi-Fi module in “TASK” tab under the description “Opto 1”.

REC
Control Your Power!

Opto1 ▾

Selected errors:

- [1] Cell/s voltage is above the maximum set threshold. (CMAX)
- [2] Cell voltage is below the maximum set threshold. (CMIN)
- [3] Cell voltages differ more than set threshold. (RAZL)
- [4] Battery temperature is above the set threshold. (TMAX)
- [5] BMS's temperature is above the set threshold. (BMAX)
- [6] Number of cells entered differ from detected.
- [7] Battery temperature too low for charging. (TMIN)
- [8] Battery temperature sensor error.
- [9] RS485 communication error.
- [10] Cell voltage measuring error.
- [11] Contactor fault
- [12] Battery current measuring error.
- [13] Wrong battery chemistry selected (CHEM)
- [14] Internal memory problems detected
- [15] Cell/s balancing transistor error
- [16] Internal error
- [17] Battery current is above the set threshold.
- [18] BMS error 18. Check the BMS's manual for error description.
- [19] BMS error 19. Check the BMS's manual for error description.

Highest cell voltage [V] ▾

Negative with OFF on ERROR ▾

Compare value:

4.15

Hysteresis:

0.1

Current value:

3.783

ON

Figure 15: Digital output configuration in Task tab - Wi-Fi module.

Control Pilot CP:

Master 10M offers two wire Control Pilot (CP) connection control. CP and AGND should be connected to the BMS. BMS controls the maximum AC charging current, when a charger is set by a dedicated charger with *CHRG* (please send note about CP and charger used when ordering).

Error Acknowledge/Forced Connect Input:

Galvanically non-isolated input is used to acknowledge the error and to force the BMS to connect the battery to the system in case of cell over-voltage (error 1) or under-voltage (error 2 with condition that all cell voltages are $> 0.85 * \text{Minimum cell voltage } CMIN$ setting). A momentary push button may be used between pins 15 and 16 on the 20-pin IOs connector. Do not apply any voltage source on either pin. Error acknowledge works as a short button press (momentary short signals between pins 15 and 16). Error alarm

is silenced, but error LEDs keep signaling the error until it disappears. Long button hold (> 1.2 s) forces battery to connect to the system in case of cell over-voltage (error 1) or under-voltage (error 2 with condition that all cell voltages are $> 0.85 * \text{Minimum cell voltage CMIN setting}$). Battery stays connected to the system for 10 s + pre-charge timer *PRCT*. If the error does not disappear, the system is disconnected again. Forced re-connect is possible after 1 min.

RS-485 Communication Protocol:

Galvanically isolated RS-485 (EN 61558-1, EN 61558-2) serves for logging and changing BMS parameters. Dedicated PC Software BMS Master Control, REC Wi-Fi module, REC LCD touch display or another RS-485 device may be used for communication. Default RS-485 Master 10M unit address is 16.

Unlock password: Serial without the first minus e.g. 2Q-XXXX, 10M-YYYY.

Messages are comprised as follows:

STX, DA, SA, N, INSTRUCTION- 4 bytes, 16-bit CRC, ETX

- STX start transmission <0x55> (always)
- DA - destination address <0x01> to <0x10> (set as 16)
- SA - sender address <0x00> (always 0)
- N – number of sent bytes
- INSTRUCTION 4 bytes for example.: LCD1? - (combined from 4 ASCII characters, followed by '?', if we would like to receive the current parameter value or ',', 'xx.xx' value in case we want to set a new value
- 16-bit CRC - big endian, for the whole message except STX in ETX - <https://www.lammertbies.nl/comm/info/crc-calculation.html>
- ETX - end transmission <0xAA> (always)

Dataflow:

- Bit rate: 56k/115k2(default) – set by the *RSBR* instruction
- Data bits: 8
- Stop bits: 1
- Parity: None
- Mode: Asynchronous
- Little endian format when an array is sent

Table 15: RS-485 instruction set.

INSTRUCTION	DESCRIPTION	BMS ANSWER	SETTING INTERVAL
*IDN?	Identification	Answer "REC-BMS"	Read only
GENERAL ARRAYS INSTRUCTIONS			
LCD1?	Main data	First answer is 28 – how many byte data will be sent and then data message follows as 7 float values: LCD1 [0] = min cell voltage, LCD1 [1] = max cell voltage, LCD1 [2] = current, LCD1 [3] = max temperature, LCD1 [4] = pack voltage, LCD1 [5] = SOC (state of charge) interval 0-1-> 1=100% and LCD1 [6] = SOH (state of health) interval 0-1-> 1=100%	Read only
LCD3?	Main data	First answer is 8 – how many byte data will be sent and then data message follows as 8 byte values: LCD3 [0] = min cell BMS address, LCD3 [1] = min cell number, LCD3 [2] = max cell BMS address, LCD3 [3] = max cell number, LCD3 [4] = max temp. sens. BMS address, LCD3 [5] = max temp. sens. number, LCD3 [6] = Ah MSB, LCD3 [7] = Ah LSB	Read only
CELL?	Cell voltages	BMS first responds with how many BMS Slave units are connected, then it sends the values of the cells in float format	Read only
PTEM?	Cell temperatures	BMS first responds with how many BMS Slave units are connected then it sends the values of the temperature sensors in float format	Read only
RINT?	Cells internal DC resistance	BMS first responds with how many BMS Slave units are connected then it sends the values in float format	Read only
BTEM?	BMS temperature	BMS first responds with value 1, then it sends the values of the BMS temperature sensor in float format	Read only
ERRO?	Error number description array	First answer is 4 – how many byte data will be sent and then data message follows as 4 byte values: ERRO [0] = 0 – no error, 1 – error ERRO [1] = BMS unit ERRO [2] = error number (1-16) and ERRO [3] = number of the cell, temp. sensor where the error occurred	Read only
WCIB?	Which cell is being balanced	BMS first responds with how many BMS Slave units are connected, then it sends unsigned integer values where each bit represents equivalent cell number.	Read only

VOLTAGE SETTINGS INSTRUCTIONS			
BVOL? or BVOL x.xx	Balance end voltage	Returns float voltage [V]	2.5 to 4.30 V
BMIN? or BMIN x.xxx	Balancing start voltage Should be set to 90 % SOC	Returns float voltage [V]	2.5 to 4.30 V
CMAX? or CMAX x.xx	Cell over-voltage switch-off	Returns float voltage [V]	2.0 to 4.30 V
MAXH? or MAXH x.xx	Cell over-voltage switch-off hysteresis per cell	Returns float voltage [V]	0.005 to 2.0 V
CMIN? or CMIN x.xxx	Cell-under voltage protection switch-off	Returns float voltage [V]	1.8 to 4.00 V
MINH? or MIN x.xxx	Cell under-voltage switch-off hysteresis per cell	Returns float voltage [V]	0.005 to 2.0 V
CHAR? or CHAR x.xxx	Cell End of charging voltage	Returns float voltage [V]	2.0 to 4.30 V
CHIS? Or CHIS x.xxx	End of charging voltage hysteresis per cell	Returns float voltage [V]	0.005 to 2.0 V
UBDI? or UBDI x.xxx	End of charging cell imbalance voltage	Returns float voltage [V]	0.001 to 0.03 V
CFVC? or CFVC x.xxx	Maximum cell float voltage coefficient	Returns float value	0.0 to 1.0
RAZL? or RAZL x.xx	Cells max difference	Returns float voltage [V]	0.005 to 1.0 V
TEMPERATURE SETTINGS INSTRUCTIONS			
TMAX? or TMAX x.xxx	cell over temperature switch-off	Returns float temperature [°C]	-20 to 65 °C
TMIN? or TMIN x.xxx	Under-temperature charging disable	Returns float temperature [°C]	-30 to 65 °C
TBAL? or TBAL x.xxx	BMS over-temperature switch-off	Returns float temperature [°C]	-20 to 65 °C
BMTH? or BMTH x.xxx	BMS over temperature switch-off hysteresis	Returns float temperature [°C]	1 to 30 °C
REC BMS SLAVE UNIT CURRENT SETTINGS INSTRUCTIONS*			
IOFF? or IOFF x.xxx	Current measurement zero offset	Returns float current [A]	-2.0 to 2.0 A
IOJA? Or IOJA x.xxx	Voltage to current coefficient broadcast to all BMS Slave units	Returns float value	0.0005 to 0.5
BATTERY PACK SETTINGS INSTRUCTIONS			
CCMX? or CCMX x.xx	Maximum system charge current	Returns float current [A]	0 to 700
DCMX? or DCMX x.xx	Maximum system discharge current	Returns float current [A]	0 to 1000
CYCL? or CYCL xx	Current number of full battery pack cycles	Returns integer value	0 to 8000
CAPA? or CAPA x.xxx	Battery pack capacity	Returns float capacity [Ah]	1.0 to 5000.0 Ah
CHEM? or CHEM xx	Cell chemistry	Returns unsigned char value	1 to 7

SOC SETTINGS INSTRUCTIONS			
SOCH? or SOCH x.xxx	SOC end of charge hysteresis	Returns float value 0 – 1.0	0.005 to 0.99
SOCS? or SOCS x.xx	SOC manual re-set	Returns float value 0 – 1.0	0.01 to 1.00
SYSTEM COMMUNICATION SETTINGS INSTRUCTIONS			
CHAC? or CHAC x.xxx	Charge coefficient (0-3C)	Returns float value 0-3.0 (default 0.6)	0.01 to 3.0
DCHC? or DCHCx.xxx	Discharge coefficient (0-3C)	Returns float value 0-3.0 (default 1.5)	0.01 to 3.0
SISN? or SISN xx	Number of inverter devices on the bus	Returns unsigned char value (default 1)	1 to 6
MAXC? or MAXC x.xxx	Maximum charge current per inverter device	Returns float current [A]	5.0 to 345.0 A
MAXD? or MAXD x.xxx	Maximum discharge current per inverter device	Returns float current [A]	5.0 to 345.0 A
CLOW? or CLOW x.xxx	cell under-voltage discharge protection set to 3-5% SOC	Returns float voltage [V]	1.8 to 4.20 V
CANS? or CANS xxx	CAN bitrate	Returns unsigned char value of 0-4 and 128-132	See Table 18
RSBR? or RSBR x	RS485 COM bitrate	Returns byte value	1 – 56k 2 – 115k2
ERROR LOG INSTRUCTIONS			
FUSE? or FUSExx	First use	Returns byte value	Setting First use to 1 clears the whole Error log after the Maser BMS is restarted and broadcasted to all BMS Slave units
ERRL?	Error log	Returns error log FiFO line, by sending Query multiple times user gets all 6 logs.	Error, BMS with error, BMS element number with error; mm:hh; dd.mm.yyy
MASTER 10M UNIT SETTINGS INSTRUCTIONS			
OP1V? or OP1V xxx	Optocoupler 1 task compare value	Returns float value	Optocoupler 1 task instruction set
OP1H? or OP1H xxx	Optocoupler 1 task compare value hysteresis	Returns positive float value	
OP1T? or OP1T xxx	Optocoupler 1 task settings	Returns unsigned long	
OP1V? or OP1V xxx	Optocoupler 1 compare current value	Returns float value	
RE1V? or RE1V xxx	Relay 1 task compare value	Returns float value	Relay 1 task instruction set
RE1H? or RE1H xxx	Relay 1 task compare value hysteresis	Returns positive float value	
RE1T? or RE1T xxx	Relay 1 task settings	Returns unsigned long	
RE1V? or RE1V xxx	Relay 1 task compare current value	Returns float value	
WHIN? or WHIN xxx	Master 10M charge Wh counter	Returns float value [Wh]	0 - ...
WHOU? or WHOU xxx	Master 10M discharge Wh counter	Returns float value [Wh]	0 - ...

WHRE x	Master 10M charge/discharge Wh counter reset	Returns "WH counter reset"	Write only
RSTN?	Master 10M Rest counter	Returns unsigned long value	Read only
NOSU? or NOSU x	Number of BMS Slave units	Returns byte value	0 - 12
SYST? or SYST x	Battery configuration	Returns byte value	0 – serial connection 1 – parallel strings Master 10M reset required after setting
CHRG? or CHRG xx	ESS/Charger CAN protocol	Returns byte value	See Table 17
SWVR?	BMS firmware version	Returns string "2.7"	Read only
HWVR?	BMS hardware version	Returns string "4.2"	Read only
DATE? or DATE xx.xx.xxxx	RTC date	dd.mm.yyyy format	Date is also broadcasted to all BMS Slave units
TIME? or TIME xx:xx:xx	RTC time	hh:mm:ss format	Time is also broadcasted to all BMS Slave units
PRCT xx	Master / BMS Slave unit integrated pre-charge timer	Returns byte value	1-16 s. Setting is broadcasted to all BMS Slave units

* Connect to the dedicated BMS Slave unit.

Parameter accepted and changed value is responded with 'SET' answer.

Example: proper byte message for 'LCD1?' instruction for BMS address 1 is:

```
<0x55><0x01><0x00><0x05><0x4C><0x43><0x44><0x31><0x3F><0x46><0xD0><0xAA>
```

RS-485 message is executed when the microprocessor is not in interrupt routine so a timeout of 350 ms should be set for the answer to arrive. If the timeout occurs the message should be sent again. Little endian format is used for all sent float or integer values. In case of single data sent ASCII characters are used e.g. - 1.2351e2. Custom made instructions can be added to the list to log or set the parameters that control the BMS algorithm or its outputs.

Video instruction link for settings change: [REC Changing Settings - YouTube](#)

Video instruction link for firmware update: [REC Firmware Update Procedure - YouTube](#)

and [REC Wi-Fi Module Update and REC BMS Firmware Update Using REC Wi-Fi Module - YouTube](#)

In case of interrupted Master/BMS Slave firmware update procedure, bootloader stays programmed in the device. To upload the firmware again ON/OFF or remote ON/OFF should be used to restart the BMS device from bootloader and enable firmware update procedure.

Master 10M RS-485 Communication with BMS Slave Units:

The Master 10M unit utilizes the same communication protocol to send instruction messages and queries asynchronously to all BMS Slave units connected on the RS-485 bus. Once the Master 10M unit completes its initial self-test, it scans the bus for available BMS Slave devices. Each BMS Slave unit should have its own distinguished RS-485 address to prevent data collision and to be properly identified. Upon detection, each BMS Slave unit is managed by the Master 10M unit, which sends instructions regarding specific operations such as performing measurements (MEAS), balancing (BALV), activating outputs (TYCO), and signaling errors (ERRO).

All BMS Slave units should be connected in a daisy-chain configuration to the RS-485 communication port of the Master 10M unit. It is essential to use a 1.2 k Ω termination plug at the last BMS Slave output port to maintain signal integrity. The Master 10M unit is equipped with an internal 1.2 k Ω termination resistor.

Table 16: RS-485 Master 10M and BMS Slave units' connector pin designator.

RS485 - DESIGNATOR	MASTER 10M RS485 Slave port (14 pin)	BMS SLAVE RS485 input port (6 pin)	BMS SLAVE RS485 output port (14 pin)
RS-485 CABLE SHIELD	12 black - shield	6 black - shield	12 black - shield
AGND - MASTER	13 - grey	5 - grey	13 - grey
RS-485 B	6 - green	1 - green	6 - green
RS-485 A	7 - yellow	2 - yellow	7 - yellow
RS-485 +5 V	14 - pink	4 - pink	14 - pink
RS-485 +5 V ENABLE	5 - white	3 - white	5 - white

CAN Communication:

CAN communication is used to communicate with the system. There are ten ESS hybrid inverter protocols pre-programmed in the BMS and three CAN supported chargers. ESS/charger selection is performed by the RS-485 instruction *CHRG*. After changing the protocol, the user may also select the CAN bitrate using RS-485 instruction *CANS*, that is updated without BMS restart. Both parameters are described in the tables below. **Galvanically isolated CAN driver with floating ground is used with isolation level up to 5000 V_{rms}. RC filters and voltage protection are used to limit the inrush current when establishing the system ground connection.**

Table 17: CHRG and CANS instruction selection list.

ESS/CHARGER	CHRG SETTING	CANS SETTING	DESCRIPTION
REC BMS CAN protocol	0	Select desired bit-rate from the table 18	250kb 11-bit ID default
Victron	1	2 or 3	250kb or 500kb @ 11-bit ID; 500kb default,
SMA	2	3	500kb @ 11-bit ID
Solax	3	3	500kb @ 11-bit ID
Studer Innotec	4	3	500kb @ 11-bit ID
Growatt	5	3	500kb @ 11-bit ID
Solis	6	3	500kb @ 11-bit ID
Pylontech, Deye, SofarSolar (LV)	7	3	500kb @ 11-bit ID
TBB power	8	3	500kb @ 11-bit ID
TC Charger	9	130	250kb @ 29-bit ID
Zivan	10	1-3 see charger settings	125kb, 250kb or 500kb @ 11-bit ID 250kb default
Custom	11	Select desired bitrate from the table	
Piktronik	12	1-4 see charger settings	250kb @ 11-bit ID
Pylontech, Deye, Sungrow (HV)	13	131	500kb @ 29-bit ID
Solis HV	14	131	500kb @ 29-bit ID

Table 18: CANS instruction description.

BAUDRATE	STANDARD 11-BIT ID	EXTENDED 29-BIT ID
100k	0	128
125k	1	129
250k	2	130
500k	3	131
1M	4	132

Examples:

250k with standard 11-bit ID, send CANS 2.

500k with extended 29-bit ID, send CANS 131.

CAN bus should be terminated at each end of the daisy chain connection. **Short pins 2 and 9 to enable 120 Ohm termination inside the BMS.** Additional RJ45 connector plug with 120 Ohms across CANL and CANH is usually used for the end device on the CAN bus for end termination.

REC BMS CAN Protocol:

11-bit TX identifiers: 0x041, 0x042, 0x043, 0x044 and 0x045.

CANS bitrate/ID is set by default to 2. User may set the desired CANS.

CAN messages are sent every 150 ms.

Table 19: CAN message description for ID=0x041.

Byte	Description	Type	
1	State of charge [%]	Unsigned char	0-200 LSB = 0.5 % SOC
2	State of health [%]	Unsigned char	0-200 LSB = 0.5 % SOH
3	Battery pack voltage high byte	Unsigned integer	0-65535, LSB = 100 mV
4	Battery pack voltage low byte		
5	Battery pack current high byte	Signed integer	-32768 to 32767 LSB = 50 mA
6	Battery pack current low byte		
7	Battery pack max temperature	Signed char	-127 to 127 LSB = 1° C
8	Battery pack min temperature	Signed char	-127 to 127 LSB = 1° C

Table 20: CAN message description for ID =0x042.

Byte	Description	Type	
1	Low cell voltage high byte	Unsigned integer	0-65535, LSB = 1 mV
2	Low cell voltage low byte		
3	High cell voltage high byte	Unsigned integer	0-65535, LSB = 1 mV
4	High cell voltage low byte		
5	Low cell – BMS Slave position	Unsigned char	1-16
6	Low cell – Slave number	Unsigned char	1-12
7	High cell – BMS Slave position	Unsigned char	1-16
8	High cell – Slave number	Unsigned char	1-12

Table 21: CAN message description for ID =0x043.

Byte	Description	Type	
1	Max temperature – BMS Slave position	Unsigned char	1-16
2	Max temperature – BMS Slave number	Unsigned char	1-12
3	Min temperature – BMS Slave position	Unsigned char	1-16
4	Min temperature – BMS Slave number	Unsigned char	1-12
5	Max BMS temperature	Signed char	-127 to 127 LSB = 1° C
6	Error number	Unsigned char	0-16
7	Error number – unit address	Unsigned char	0-12
8	Error number – unit position	Unsigned char	0-16

Table 22: CAN message description for ID =0x044.

Byte	Description	Type	Property
1	Charge voltage high byte	Unsigned integer	LSB = 0.1 V
2	Charge voltage low byte		
3	Max charging current high byte	Signed integer	LSB = 0.1 A
4	Max charging current low byte		
5	Max charging current high byte	Signed integer	LSB = 0.1 A
6	Max charging current low byte		
7	Discharge voltage high byte	Unsigned integer	LSB = 0.1 V
8	Discharge voltage low byte		

Table 23: CAN message description for ID =0x045.

Byte	Description	Type	Property
1	Discharged Ah high byte	Unsigned integer	LSB = 1 Ah
2	Discharged Ah low byte		
3	Connection status	Unsigned char	0 - unconnected 1 - pre-charge 2 - connected 3 - shutting down
4	Relay status	Unsigned char	Bit 1 – Relay 1 Bit 2 – Relay 2 Bit 3 – Relay 3 Bit 4 – Relay 4 Bits 5-8 not used - 0

Victron

11-bit TX ID identifiers: 0x351, 0x355, 0x356, 0x35A, 0x35E, 0x35F, 0x360, 0x372, 0x373, 0x374, 0x375, 0x376, 0x377, 0x378, 0x379, 0x380 and 0x381.

11-bit RX heartbeat 0x305 message from GX unit is neglected.

CANS bitrate/ID is set by default to 3. The user can set the preferred CANS value to 2.

CAN messages are sent every 150 ms. Use the RJ45 CAN BMS input on Cerbo/Ekrano with 500k or 250k for Ve.CAN connection.

RJ45 pinout: 3: CAN GND, 7: CANH, 8: CANL

SMA

11-bit TX ID identifiers: 0x351, 0x355, 0x356, 0x35A, 0x35E and 0x35F

CANS bitrate/ID is set by default to 3. User may set the desired CANS.

CAN messages are sent every 200 ms.
RJ45 pinout: 2: - CAN GND, 4: CANH, 5: CANL

Solax

11-bit TX ID identifiers: 0x351, 0x355, 0x356, 0x359, 0x35C and 0x35E
CANS bitrate/ID is set by default to 3. User may set the desired CANS.
CAN messages are sent every 200 ms.

Studer Innotec

11-bit TX ID identifiers: 0x351, 0x355, 0x356, 0x359, 0x35C and 0x35E
CANS bitrate/ID is set by default to 3. User may set the desired CANS.
CAN messages are sent every 200 ms.
RJ45 pinout: 2: - CAN GND, 4: CANH, 5: CANL or user defined with Xcom-CAN device

Growatt

11-bit TX ID identifiers: 0x311, 0x312, 0x313, 0x314, 0x315, 0x316, 0x317, 0x318, 0x319, 0x320 and 0x321
CANS bitrate/ID is set by default to 3. User may set the desired CANS.
CAN messages are sent every 100 ms.

Solis ESS

11-bit TX ID identifiers: 0x351, 0x355, 0x356, 0x359
CANS bitrate/ID is set by default to 3. User may set the desired CANS.
CAN messages are sent every 150 ms.

Pylontech/Deye ESS

11-bit TX ID identifiers: 0x351, 0x355, 0x356, 0x359, 0x35C and 0x35E
CANS bitrate/ID is set by default to 3. User may set the desired CANS.
CAN messages are sent every 100 ms.

TBB

11-bit TX ID identifiers: 0x351, 0x355, 0x356, 0x359, 0x35C and 0x35E
CANS bitrate/ID is set by default to 3. User may set the desired CANS.
CAN messages are sent every 100 ms.

TcCharger

29-bit TX ID identifiers: 0x1806E5F4, 0x1806E7F4 and 0x1806E9F4 + REC BMS CAN protocol
CANS bitrate/ID is set by default to 130. User may set the desired CANS to 131. Maximum charging current per device *MAXC* is multiplied by Charge current coefficient *CHCU* and sent to all three IDs.
Number of inverters/chargers *SISN* should be set properly to enable proper error 17 check.
CAN messages are sent every 100 ms.

Zivan

11-bit TX ID identifiers: 0x6C1 and 0x6A1 + REC BMS CAN protocol
CANS bitrate/ID is set by default to 2. User may set the desired CANS.
CAN messages are sent every 100 ms.

Custom

If a custom CAN protocol is required, REC Team can implement it as a CUSTOM protocol set as *CHRG* = 11.
CANF may be changed to the desired bitrate and ID length.

Piktronik chargers

11-bit TX ID identifiers: 0x181+ REC BMS CAN protocol

CANS bitrate/ID is set by default to 2. User may set the desired CANS.

CAN messages are sent every 100 ms.

Pylontech HV

29-bit TX ID identifiers: 0x4210, 0x4220, 0x4230, 0x4240, 0x4250, 0x4260, 0x4270, 0x4280, 0x4290, 0x7310, 0x7320, 0x7330, and 0x7340.

CANS bitrate/ID is set by default to 131.

CAN messages are sent every 80 ms.

Solis HV

29-bit TX ID identifiers: 0x1801, 0x1872, 0x1873, 0x1874, 0x1875, 0x1876, 0x1877 and 0x1878.

CANS bitrate/ID is set by default to 131.

CAN messages are sent every 80 ms.

Master 10M Unit Start Procedure:

When the Master 10M unit is turned ON it commences the internal initialization procedure, enables RS-485 +5 V ENABLE BMS Slave supply and after 4 s starts searching for BMS Slave units on the RS-485 Slave bus. If no BMS Slave unit is detected, error 9 is signaled and the BMS stays in the BMS Slave detection mode. If Master 10M unit detects different number of BMS Slave units than programmed by Number of Slave units “NOSU” setting, BMS goes to normal operation without starting the relays for connection and alarms error 21. “XXXX” should be used to properly set number of BMS Slave. When set, a restart is required to eliminate error 20.

Master 10M Unit LED Indication:

The Power LED (green) provides clear visual feedback regarding the status of the battery pack. Its signaling patterns are as follows:

- Low State of Charge (SOC): Indicated by a single ON blink of the green Power LED.
- Normal Operating Mode: Indicated by two consecutive ON blinks of the Power LED.
- Balancing Mode: Indicated by three consecutive ON blinks before a longer pause in the blinking sequence.
- Fully Charged State: When the battery pack is fully charged and the SOC/*End of Charge Hysteresis* settings are reached, the Power LED (green) remains continuously illuminated at 100%.

The Error LED (red) serves as a visual indicator of system errors. When a system error occurs, the Error LED illuminates and signals the specific error number. The signaling pattern is as follows: the LED blinks with a 50% duty cycle to represent the error number. After each complete sequence indicating the error number, there is a 1-second timeout before the error indication pattern repeats. This blinking sequence allows users to identify the nature of the system error by counting the number of blinks displayed by the Error LED.

Voltage/Temperature Hysteresis:

Most of the BMS setting thresholds also have a dedicated hysteresis parameter. This way the BMS prevents ringing due to the oscillation of the controlled parameter above and under the set threshold. If the threshold limits the top value of the parameter like Maximum cell voltage CMAX or temperature TMAX, the value of hysteresis should be **negative** to prevent the ringing. If the threshold limits the bottom value of the parameter like Minimum cell voltage CMIN or temperature TMIN the value of hysteresis should be **positive** to prevent the ringing. For simplicity, all the BMS settings are set without the sign and the BMS firmware takes care of proper sign value.

BMS Cell Balancing:

Cells are balanced passively by discharging each cell through a 3.9 Ω power resistor. Since the balancing resistors dissipate heat, an additional temperature measurement inside the enclosure of the BMS unit is performed to prevent overheating the integrated circuits. If the BMS temperature rises above the set threshold, balancing is stopped. BMS error 5 is indicated until the temperature drops under the set hysteresis value. Master 10M unit sends the instructions to each BMS Slave unit individually, which cells should be balanced. If the BMS Slave unit does not get a refreshed value in 5 s, all balancing is switched off.

Balancing START Voltage (BMIN):

If errors 2, 4, 5, 8, 10, 12 are not present, the charging current is above 0.2 A and at least one cell's voltage rises above the balancing start voltage threshold, the BMS initiates the balancing algorithm. The algorithm calculates a weighted cell voltage average which considers the internal DC resistance of each cell. Based on the calculated average the BMS determines which cell will be balanced. BMIN cell voltage setting should be set to the voltage that corresponds to 90 % of the usable capacity.

Balancing Voltage END (BALV):

If errors 2, 4, 5, 8, 10, 12 are not present, any cell above balance END voltage is balanced regardless of the battery pack's current.

Cell Internal DC Resistance Measurement:

Cell internal DC resistance is measured as a ratio of a voltage change and current change in two sequential measurement cycles. If the absolute current change is above 15 A, cell's internal resistance is calculated. Moving average is used to filter out voltage spikes errors.

Battery Pack SOC/SOH Determination:

SOC is determined by integrating the charge into or out of the battery pack. Different Li-ion chemistries may be selected:

Table 24: Li-ion chemistry designators.

NUMBER	TYPE
1	Li-Po Kokam High power
2	Li-Po Kokam High capacity
3	Winston/Thunder-Sky/GWL LiFePO ₄
4	A123
5	Li-ion NMC/ LiMn ₂ O ₄
6	LTO
7	Li-ideal
8	Custom
9	Sodium-ion

Temperature and power correction coefficient are taken into consideration at the *State of charge* (SOC) calculation. Li-Po chemistry algorithms have an additional voltage-to-SOC regulation loop inside the algorithm. BMS calculates battery self-discharge upon selected chemistry, SOC and temperature. *State of health* (SOH) is calculated as number of cycles compared to battery end-of-life cycles and compensated with SOH and temperature. Operational capacity is recalculated by the number of charging cycles as pointed out in the cells' manufacturer's datasheet.

When BMS is connected to the battery pack for the first time, SOC is set to 50 %. SOC is reset to 100 % at the end of charging. Charging cycle is added if the coulomb counter had reached the *Battery Pack's Capacity* CAPA.

Battery Pack's Charging Algorithm:

The communication between the REC Master 10M unit and the inverter/charger is established through the CAN bus. All the parameters that control the charging/discharging behavior are calculated by the BMS and transmitted to external display (if applicable) in each measurement cycle.

The charging current is controlled by the Maximum charging current parameter. It's calculated as *Charge Coefficient CHAC x Battery capacity CAPA x parallel Strings*. The parameter has an upper limit which is defined as *Maximum Charging Current per Device MAXC x Number of Inverter/Charger Devices SISN*. Lowest value is selected:

Table 25: Maximum charging current calculation.

SETTING	VALUE	UNIT
Battery Capacity (CAPA)	100	Ah
Parallel Strings Detected	2	n.a.
Charge Coefficient (CHAC)	0.6	1/h
Maximum Charging Current per Device (MAXC)	75	A
Number of Inverter/Charger Devices (SISN)	2	n.a.

Charge Coefficient CHAC x Battery Capacity CAPA x parallel strings = 0.6 1/h x 100Ah x 2 = 120 A
Maximum Charging current per device MAXC x Number of Inverter/Charger devices SISN = 75 A x 2 = 150 A

Maximum charging current is set to **120 A** due to lower value of the *Charge Coefficient CHAC x Battery Capacity CAPA x parallel strings*.

When the cell with the highest voltage reaches the *End of Charge (CHAR)* voltage setting, the charging current starts to decrease down to 1.1 A x *Number of Inverter/Charger Devices SISN* until the last cell rises near the *End of Charge Voltage CHAR (CC/CV)*. This step ensures that all cells approach the End of Charge Voltage CHAR in a controlled manner. At that point the Maximum charging voltage allowed is set to *Number of cells x (End of Charge Voltage per cell CHAR – Maximum Cell Float Voltage Coefficient CFVC x End of charge hysteresis per cell)*. *End of Charge SOC hysteresis SOCH* and *End of charge cell voltage hysteresis CHIS* is set to prevent unwanted switching. If CFVC is set to 0.0, charging current is set to 0.0 A until the *End of Charge Hysteresis CHIS* and *End of Charge SOC hysteresis SOCH* have been met.

Once these conditions are met, the State of Charge (SOC) is calibrated to 100%, and the Power LED is illuminated to indicate full charge. At this stage, the Charger Enable Relay 1 is turned off. The maximum allowed charging current is then set to 50% of its original value, which allows for the supply of DC loads from charging devices such as MPPTs.

Charging current is limited to 30% of the maximum charging current, but remains above 5 A near both temperature extremes — specifically at the maximum cell temperature (TMAX) and the minimum allowable temperature for charging (TMIN) — and also when the battery is empty, at which point the maximum discharging current is set to zero.

Charging is stopped in case of systems errors (See System Errors indication chapter). SOC is calibrated to 96 % when the maximum open circuit cell voltage rises above the $0.502 \times (\text{Balance start voltage BMIN} + \text{End of charge voltage CHAR})$, minimum open circuit voltage above balance start voltage and system is in charge regime.

BMS forces a full charge if the pack was not fully charged for more than three weeks.

In case BMS cannot control the MPPT charging sources directly (MPPT should be set to charge when the remote is in short), Relay 1 can be used to control the charger. MPPT should be programmed with its own charging curve set as *End of charge voltage x number of cells*.




Figure 16: Charging diagram.

Maximum Cell Float Voltage Coefficient (CFVC):

Maximum Cell Float Voltage Coefficient CFVC has been introduced into the charging algorithm to enable cell float voltage change after the full charge. It may be set from 0.0 to 1.0 of the *End of Charge Hysteresis* CHIS. When *End of Charge Hysteresis* CHIS and *End of Charge SOC hysteresis* SOCH have been met, full charge is enabled again. @ CFVC 50 % of maximum charging current is allowed to supply DC loads from MPPTs directly without discharging the battery pack below *End of Charge Hysteresis* CHIS and *End of Charge SOC hysteresis* SOCH. If CFVC is set to 0.0, charging current is set to 0.0 A until the *End of Charge Hysteresis* CHIS and *End of Charge SOC hysteresis* SOCH have been met.

Battery Pack's Discharging Algorithm:

When the BMS recovers from the error or from *Discharging SOC hysteresis*, maximum allowed discharging current is set. It is calculated as *Discharge Coefficient DCHC x Battery Capacity CAPA x parallel strings*. If this value is higher than *Maximum Discharging Current per device MAXD x Number of Inverter/Charger Devices SISN*, maximum discharging current is decreased to this value.

Table 26: Maximum discharging current calculation.

SETTING	VALUE	UNIT
Battery Capacity (CAPA)	100	Ah
Parallel Strings detected	2	n.a.
Discharge Coefficient (DCHC)	1.5	1/h
Maximum Discharging Current per Device (MAXC)	100	A
Number of Inverter/Charger Devices (SISN)	2	n.a.

Discharge Coefficient DCHC x Battery Capacity CAPA x parallel strings = 1.5 1/h x 100Ah x 2 = 300 A
Maximum Discharging Current per device MAXC x Number of Inverter/Charger devices SISN = 100 A x 2 = 200 A

Maximum discharging current is set to **200 A**.

When the lowest cell open circuit voltage is discharged below the set threshold CLOW, maximum discharging current starts to decrease down to 0.02 C (2 % of Capacity CAPA in A). After decreasing down, maximum allowed discharging current is set to 0 A. At discharge currents lower than 0.05 C or positive, SOC is reset to 3 % and Discharging SOC hysteresis is set to 5 %. If the cell discharges below *Minimum Cell voltage CMIN*, BMS signals Error 2. If the battery current is lower than 0.05 C or positive, SOC is reset to 1 %. If the charger/inverter is connected to the grid, maximum allowed discharge current is drawn from the grid.

Otherwise, 100 % load current is drawn from the battery until maximum allowed discharging current is set to 0 A. Discharging current is also limited near both ends of temperature (*Max cell temperature TMAX* and *Min temperature for charging TMIN*) to 30 %, but more than 5 A. If the minimum cell discharges under the *Cell-under voltage protection switch-off CMIN x 0.95* for more than 30 s, BMS goes to deep sleep mode to protect the cells from over-discharging. OFF-ON switch sequence wakes the BMS from this state. CLOW cell voltage setting should be set to the voltage that corresponds to 3 % of the usable capacity.




Figure 17: Discharging diagram.

System Error Indication:

System errors are visually indicated on both the Master 10M unit and the BMS Slave units by **red** error LED. The specific error is communicated through a sequence of ON blinks, with the number of blinks corresponding to the error code, followed by a longer OFF state. Every error number trigger algorithm uses a standard delay of 3 measurement cycles (3 x 1.25 s) with detected errors before triggering.

Errors 2 and 10 are set to trigger at the first measured error when the BMS is turned ON. If the two errors are not present at startup, the standard delay timer is applied.

Table 27: BMS error states.

NUMBER OF ON BLINKS	ERROR	BMS	OWNER
1	Single or multiple cell voltage is too high (cell over voltage switch-off per cell CMAX - cell over-voltage switch-off hysteresis per cell MAXH).	BMS will try to balance down the problematic cell/cells to safe voltage level (2.5 s error hysteresis + single cell voltage hysteresis is applied). Charging is disabled; discharging is enabled. Master 10M unit Relay 2 and 4 are disconnected. Charge Relay 1 is disabled.	<ul style="list-style-type: none"> Wait until the BMS does its job or use force connect.
2	Single or multiple cell voltage is too low (cell under voltage protection switch-off per cell CMIN + under voltage protection switch-off hysteresis per cell MINH).	BMS will try to charge the battery (2.5 s error hysteresis + single cell voltage hysteresis is applied). SOC is reset to 1 % in case of discharge current lower than 0.05C or positive. Charging is enabled; discharging is disabled. Master 10M unit Relay 2 and 4 are disconnected. Charge Relay 1 is disabled.	<ul style="list-style-type: none"> Plug in the charging sources. Lower MIN V_{Cell} setting CMIN for enabling the internal relay. Use force connect to charge.
3	Cell voltages differs more than set (cells max difference RAZL – 20 mV hysteresis)	BMS will try to balance the cells if balancing is enabled (20 mV voltage difference hysteresis). Charging is enabled; discharging is enabled. Master 10M unit Relay 2 and 4 are connected. Charge Relay 1 is enabled.	<ul style="list-style-type: none"> Wait until the BMS does its job. If the BMS is not able to balance the difference in a few hours, contact the service.
4	Cell temperature is too high (cell over temperature switch-off TMAX + cell over temperature switch-off hysteresis → 2°C).	Cells temperature or cell inter-connecting cable temperature in the battery pack is/are too high. (2.5 s error hysteresis 2°C hysteresis). Charging is disabled; discharging is disabled. Master 10M unit Relays 2 and 4 are disconnected. Charge Relay 1 is disabled.	<ul style="list-style-type: none"> Wait until the pack cools down.

5	BMS temperature is too high –internal error (BMS over temperature switch-off TBAL - BMS over-temperature switch-off hysteresis BMTH).	Due to extensive cell balancing/hardware error the BMS temperature rose over the upper limit (2.5 s error hysteresis - 5 °C temperature hysteresis). Charging is enabled; discharging is enabled. Master 10M unit Relays 2 and 4 are connected. Charge Relay 1 is enabled.	<ul style="list-style-type: none"> • Wait until the BMS cools down.
6	Number of cells and/or address is not set properly.	Charging is disabled; discharging is disabled. All relays are disconnected.	<ul style="list-style-type: none"> • Set proper BMS Slave unit address
7	The temperature is too low for charging (under-temperature charging disable TMIN + under temperature charging disable hysteresis of 2°C).	If cells are charged at temperatures lower than operating temperature range, cells are aging much faster than they normally would, so charging is disabled (2 °C temperature hysteresis). Charging is disabled; discharging is enabled. Master 10M unit Relays 2 and 4 are connected. Charge Relay 1 is disabled.	<ul style="list-style-type: none"> • Wait until the battery's temperature rises to usable range.
8	Temperature sensor error.	Temperature sensor is un-plugged or not working properly (2.5 s error hysteresis). Charging is disabled; discharging is disabled. Master 10M unit Relays 2 and 4 are disconnected. Charge Relay 1 is disabled.	<ul style="list-style-type: none"> • Turn-off BMS Slave unit and try to re-plug the temp. sensor. If the BMS Slave still signals error 8, contact the service. The temperature sensors should be replaced.
9	Communication error.	RS-485 Master-Slave communication only. Charging is disabled; discharging is disabled. Master 10M unit Relays 2 and 4 are disconnected. Charge relay 1 is disabled.	
10	Cell in short circuit or BMS measurement error (Max cell voltage > 4.5 V or Min cell voltage < 0.8 V).	Single or multiple cell voltage is close to zero or out of range, indicating a blown fuse, short circuit or measuring failure (15 s error hysteresis + 10 mV voltage difference hysteresis). Charging is disabled; discharging is disabled. Master 10M unit Relays 2 and 4 are disconnected. Charge Relay 1 is disabled.	<ul style="list-style-type: none"> • Turn off the Master 10M unit and check the cells connection to the BMS and fuses. Restart the Master 10M unit. • If the same error starts to signal again contact the service.

11	Main relay is in short circuit.	If the main relay should be opened and current is not zero or positive, the BMS signals error 11. Charging is disabled; discharging is disabled. Master 10M unit Relays 2 and 4 are disconnected. Charge Relay 1 is disabled.	<ul style="list-style-type: none"> Restart the Master 10M unit. If the same error starts to signal again contact the service.
12	Current measurement disabled or charging/discharging current >2 x shunt max current	BMS cannot measure current or current is too high (short circuit). Charging is disabled; discharging is disabled. Master 10M unit Relays 2 and 4 are disconnected. Charge relay 1 is disabled.	<ul style="list-style-type: none"> Check the system settings/HW configuration. If the BMS still signals error 12, contact the service or change the BMS settings.
13	Wrong cell chemistry CHEM selected.	In some applications the chemistry pre-set is compulsory. Charging is disabled; discharging is disabled. Master 10M unit Relays 2 and 4 are disconnected. Charge Relay 1 is disabled.	<ul style="list-style-type: none"> Use PC Control Software/Wi-Fi module to set proper cell chemistry.
14	EEPROM data corruption	During start-up or shut-down EEPROM read/write was interrupted. The corrupted settings were set to a default value. If the settings were changed after the first installation they should be corrected. Charging is enabled; discharging is enabled. Master 10M unit Relays 2 and 4 are connected. Charge Relay 1 is enabled.	<ul style="list-style-type: none"> Use PC Control Software/Wi-Fi module to set proper settings.
15	Cell balancing/measurement failure	During the start-up a burned fuse or cell balancing failure was detected. Charging is enabled; discharging is enabled. Master 10M unit Relays 2 and 4 are connected. Charge Relay 1 is enabled.	<ul style="list-style-type: none"> Restart the Master 10M unit. If the same error starts to signal again contact the service.
16	BMS internal communication failure	I2C or SPI communication failure. BMS signals error 16 and does not start normal procedure Charging is disabled, discharging is disabled. Master 10M unit Relays 2 and 4 are disconnected. Charge Relay 1 is disabled.	<ul style="list-style-type: none"> Restart the BMS Slave unit. If the same error starts to signal again contact the service.

17	Charging/discharging current > 1.2 x current charging/discharging max limit	Battery current is out over the set limit. Maximum allowed charging/discharging current is reduced. Charging is enabled; discharging is enabled. Master 10M unit Relays 2 and 4 are connected. Charge Relay 1 is enabled.	<ul style="list-style-type: none"> • Wait until the Master 10M unit reduces the charge/discharge battery current.
18	Parallel string current distribution error	Battery current over the parallel string is not distributed evenly. One or more strings detects very low current – possible fuse/contactors failure. Charging is enabled; discharging is enabled. Master 10M unit Relays 2 and 4 are connected. Charge Relay 1 is enabled.	<ul style="list-style-type: none"> • Check the parallel string packs and their contactors
19	Parallel string Voltage/SOC difference	String battery sub-packs have different voltage/SOC levels and should not be connected in parallel due to high balancing equalization in-rush current. Charging is disabled; discharging is disabled. Master 10M unit Relays 2 and 4 are disconnected. Charge Relay 1 is disabled.	<ul style="list-style-type: none"> • Connect higher voltage/SOC strings and try to discharge them or charge lower voltage/SOC sub-packs. <i>NOSU</i> must be set accordingly, and only dedicated Slave units must be turned on.
20	Cell-under-voltage lock < 0.9 * CMIN	Some application requires cell under-voltage Lock. Unlock is performed by special instruction set after battery inspection. Charging is disabled; discharging is disabled. Master 10M unit Relays 2 and 4 are disconnected. Charge Relay 1 is disabled.	<ul style="list-style-type: none"> • Contact REC for implementation instructions.
21	Master 10M does not find set number of BMS Slave <i>NOSU</i> in the system	Master 10M did not discover set <i>NOSU</i> number of BMS Slave on the Master-Slave RS485 bus. Charging is disabled; discharging is disabled. Master 10M unit Relays 2 and 4 are disconnected. Charge relay 1 is disabled.	<ul style="list-style-type: none"> • Check if <i>NOSU</i> is set properly or why Master 10M did not find <i>NOSU</i> number of Slave units. Check communication cables, RS485 addresses, termination and if all BMS Slave are turned on/start.

BMS Slave Unit Dimensions:




Figure 18: BMS Slave unit dimensions.

Master 10M Unit Dimensions:




Figure 19: Master 10M unit dimensions.